

Stanica : Borovnice
 Veličina: Hladina Svratka_Borovnice
 Křivka : Q-průtok
 Typ : Měrná křivka
 Poznámka: Aktualizace MKP dle ČHMÚ - 15.10.01
 Počet : 31

Měrná křivka průtoků
stanice: Borovnice
tok: Svratka

ROZŠÍŘENÁ KŘIVKA

[cm]	/ [m3/s]									
	0	1	2	3	4	5	6	7	8	9
40	0.000	0.016	0.032	0.048	0.064	0.080	0.104	0.128	0.152	0.176
50	0.200	0.227	0.254	0.281	0.308	0.335	0.366	0.397	0.428	0.459
60	0.490	0.526	0.562	0.598	0.634	0.670	0.716	0.762	0.808	0.854
70	0.900	0.954	1.008	1.062	1.116	1.170	1.230	1.291	1.351	1.412
80	1.472	1.539	1.605	1.672	1.738	1.805	1.878	1.951	2.024	2.097
90	2.170	2.249	2.328	2.407	2.486	2.565	2.650	2.735	2.820	2.905
100	2.990	3.084	3.178	3.272	3.366	3.460	3.554	3.648	3.742	3.836
110	3.930	4.037	4.143	4.250	4.356	4.462	4.569	4.675	4.782	4.888
120	4.995	5.113	5.232	5.350	5.469	5.587	5.706	5.824	5.943	6.061
130	6.180	6.311	6.442	6.573	6.704	6.835	6.966	7.097	7.228	7.359
140	7.490	7.633	7.776	7.919	8.062	8.205	8.348	8.491	8.634	8.777
150	8.920	9.075	9.230	9.385	9.540	9.695	9.850	10.005	10.160	10.315
160	10.470	10.637	10.804	10.971	11.138	11.305	11.472	11.639	11.806	11.973
170	12.140	12.320	12.500	12.680	12.860	13.040	13.220	13.400	13.580	13.760
180	13.940	14.132	14.324	14.516	14.708	14.900	15.092	15.284	15.476	15.668
190	15.860	16.064	16.268	16.472	16.676	16.880	17.084	17.288	17.492	17.696
200	17.900	18.116	18.332	18.548	18.764	18.980	19.196	19.412	19.628	19.844
210	20.060	20.289	20.518	20.747	20.976	21.205	21.434	21.663	21.892	22.121
220	22.350	22.590	22.830	23.070	23.310	23.550	23.790	24.030	24.270	24.510
230	24.750	24.995	25.240	25.485	25.730	25.975	26.220	26.465	26.710	26.955
240	27.200	27.460	27.720	27.980	28.240	28.500	28.760	29.020	29.280	29.540
250	29.800	30.070	30.340	30.610	30.880	31.150	31.420	31.690	31.960	32.230
260	32.500	32.775	33.050	33.325	33.600	33.875	34.150	34.425	34.700	34.975
270	35.250	35.525	35.800	36.075	36.350	36.625	36.900	37.175	37.450	37.725
280	38.000									